

Set Value

The Set Value is sometimes also referred to as a desired value. It is the input value to a control unit that sets the desired control operating point from which the output is set and to which the actual value is compared with a closed loop control.